Compass Chair dimensions

User dimensions (inches)	R310 size 1	R320 size 2	R330 size 3	R340 size 4	R350 size 5
Height	36 – 45	43-50	48-57	55-65	65+
Knee to heel	9-13	101/2-141/2	121/2-161/2	141/2-181/2	161/2-201/2
Min-max thigh circumference for pelvic harness	101/2-231/2	12-281/2	141/2-301/2	15-341/2	171/2-381/2



Key user dimension: height / knee to heel

The user's overall height and measurement from knee to heel is a general guide to help you select the appropriate chair. Choose the model that allows for growth.

Important: Make sure that seat width, depth and height are adequate for each user, and that the user's weight does not exceed the maximum working load.

Item dimensions (inches)	R310	R320	R330	R340	R350
Seat height—in 1" increments	9-13	101/2-141/2	121/2-161/2	141/2-181/2	161/2-201/2
Seat depth	91/2	11	12¾	14¾	161/2
Seat width	10½	121/4	14	161/4	181⁄4
Backrest height	91/2	11	121/2	141/4	16
Armrest height above the seat	51/2	6	7	81/4	8¾
Armrest length	61/2	71/2	81/2	9¾	11
Max. working load (lb)	100	120	175	220	250

2025 order form

Scan for sizing and pricing: https://www.rifton.com/compasschair



Use dimension chart to select appropriate size.

		R310 size 1		R320 size 2		R330 size 3		R340 size 4		R350 size 5	
*Compass chair		R311	\$200 🗌	R321	\$230 🗌	R331	\$260 🗌	R341	\$290 🗌	R351	\$320 🗌
*Leg type CHOOSE	Short	R314	\$155 🗌	N/A		N/A		N/A		N/A	
	Short (low friction)	R334	\$155 🗌	N/A		N/A		N/A		N/A	
	Standard	R315*	\$155	R315	\$155 🗌						
	Standard (low friction)	R335*	\$155 🗌	R335	\$155 🗌						
New! Front stability feet (pair)		R326	\$40 🗌								
New! Rear stability feet (pair)		R327	\$40 🗌								
New! Dynamic feet (set of four)		R328	\$100 🗌								
Seat belt		R312	\$48 🗌	R312	\$48 🗌	R332	\$48 🗌	R342	\$48 🗌	R342	\$48 🔲
Pelvic harness		R313	\$180 🗌	R323	\$190 🗌	R333	\$200 🗌	R343	\$210 🗌	R353	\$220 🗌

^{*} Required

^{*} The standard legs can be used on size 1, but the lower two positions will not be accessible.

